

METER

Ultrasonic level transmitter

825B105C


Technical Data

Housing material: PBT/PP wetted part
 Mechanical installation: 2" GAS M on request PP flange
 DN50 or DN80
 Protection degree: IP65
 Electrical connection: Internal push actuators connectors
 Working temperature: -30 ÷ +70°C; +80°C non-continuous
 Pressure: from 0,5 to 1,5 bar (absolute)
 Power supply: 2-wire: 20÷30 Vdc / 4-wire: 24Vdc
 Power consumption: 2-wire max 0,6W / 4-wire max 1,5W
 Relays output: (4-wire only) -n°2 3A 230Vac
 Digital communication: 4-wire: RS485 / HART (optional)
 Max measure range : standard max 0.25÷5m (In case of non perfectly reflecting surfaces, the maximum distance value will be reduced)
 Blind distance: 0.25m
 Temperature compensation: digital from -30 to 80°C
 Accuracy: ±0,15 % (of the measured distance)
 not better than ±3mm
 Resolution: 1mm
 Calibration: 4 buttons or by HART/RS485
 Warm-up: 1 minutes typical
 LCD Display : Plug-in display/keyboard
 4 buttons matrix LCD




METER

Ultrasonic level transmitter




METER Mechanical Installation

Important!!! close to the sensor there is a "blind zone" of 0.25m where the instrument can't measure (see fig.3). To reach a good and safe measurement, avoiding spurious echoes (not reflected by the surface), take care of the positioning of the METER sensor and check that no obstacles are interfering with the ultrasonic waves emission lobe (see fig.2).



applied solution for the application

LOW Outline dimensions



METER Electrical connections

Unscrew and remove the cover to reach the the plug-in display/keypad module. By pressing the drawing-spring as shown in Fig.6 -part.1 extract the module and gain the electrical (plug-in) connectors.

See Fig.7 for 2-wire versions: METER-1;METER-2 (HART); METER-3 (ATEX)

See Fig.8 for 2 relays version: METER-4




Fig.6




Fig.7




Fig.8



Calibration

The METER configuration and calibration can be done in two different ways: by HART (Hand-Held or PC Modem) if available

- by HART Hand-Held (if available for the selected version)
- by the plug-in / keyboard module

HART Hand Held connection (fig.9)

- 1) Hand Held
- 2) METER with HART communication protocol
- 3) 250ohm resistance




Fig.9

PC/MODEM HART connection (Fig.10)

- 1) RS232 connector
- 2) METER with HART communication protocol
- 3) 250ohm resistance
- 4) HART MODEM





Fig.10







Programming display

The programming display (fig.11) has a large matrix LCD. The operating manual allows an easy and fast start up through the keyboard (fig.11)



- 1) Display LCD
- 2) Tasti di programmazione

Fig.11

-  Il tasto “**OK**” consente di confermare la selezione del cursore e dei valori numerici inseriti
-  Il tasto “” consente di muovere dall'alto verso il basso il cursore di selezione alla cifra adiacente verso DX nei campi di inserimento numerico
-  Il tasto “” consente di variare le cifre nei campi di inserimento numerico
-  Il tasto “**BK**” consente di ritornare alla finestra da cui si proviene



The menù structure is shown on pages 17/18.

From "RUN" mode, press **OK** to enter "PROGRAM" mode. Press **BK** to quit

Press **↶** to move the cursor on the parameter you want to use and confirm with **OK**

To edit numbers, press **↑** to modify the digit shown in negative, press **↶** to edit the next digit, press **OK** to confirm and store the number. Press **BK** to quit

Programming menù

1. **SETUP** – in this menù it's possible to set the basic adjustment of the sensor
2. **DISPLAY** – in this menù it's possible to setup the sensor display mode and adjust the B/W contrast of LCD
3. **DIAGNOSTIC** - in this menù it's possible to test and check the sensor, display peak values and measure status.
4. **SERVICE** - in this menù it's possible to set com mode, output mode, language, input password to enable parameters
5. **INFO** - this menù show firmware revision, serial number and manufacturer information

SETUP (1)

From "RUN" mode press **OK** then move the cursor on "SETUP" and confirm with



Select the parameters by moving the cursor with **↶**, and confirm with **OK**



ACTUAL LEV. 4mA :

press **OK** to associate the actual measure with 4mA output value; the following message will be displayed:
OK TO CONFIRM press **↶** to confirm

ACTUAL LEV. 20mA:

press **↑** to associate the actual measure with 20mA output value; the following message will be displayed:
OK TO CONFIRM press **OK** to confirm



SET DISTANCE 4mA:

press **OK** to display the value of distance associated with 4mA output; use **↑** and **↺** to modify that value. Confirm with **OK**



SET DISTANCE 20mA:

press **OK** to display the value of distance associated with 20mA output; use **↑** and **↺** to modify that value. Confirm with **OK**



MEDIUM:

select LIQUIDS if the sensor is measuring a liquid level, else select SOLIDS



FILTER COEFFICIENT:

input a value from 1 to 100 (10 default) to smooth the response of the sensor: the biggest is the value, the smoothest is the response



BLIND DISTANCE:

represent the "BLIND ZONE" of the sensor. Input the desired value in order to avoid measures near the surface of the sensor (if necessary). The minimum value is 250mm





RELAY:


in this sub-menù it's possible to setup onboard relays (only LOW-4 model).

RL1 can be set as **threshold** relay or **pump-control** relay; RL2 can be set as **threshold** relay or **diagnostic** relay



RL1 THRESHOLD/RL2 THRESHOLD:

select the parameter by moving the cursor with  and confirm with 



VALUE:

it's possible to input the threshold value, **in terms of percentage of level**



MIN/MAX:

it's possible to select if the relay works as maximum level threshold or minimum level threshold



DELAY:

it's possible to select the delay of activation for the selected relay, from 0 to 99 sec. (0s default)




SAFETY:

it's possible to select if the coil of relay is normally EXCITED (YES) or normally DISEXCITED (NO)




ENABLE/DISABLE:

select ENABLE to allow the relay to work in the selected mode (Threshold/Pump or Threshold/Diagnostic)




RL1 PUMP:


it's possible to allow **pump control** with RL1, also in **FILLING** mode or **EMPTYING** mode.




FILLING MODE



EMPTYING MODE

Select the parameter by moving the cursor with  and confirm with **OK**




UPPER:

it's possible to input the upper level value, to enable start emptying or stop filling.



LOWER:

it's possible to input the lower level value, to enable stop emptying or start filling.




DELAY:

it's possible to select the delay of activation for the selected relay, from 0 to 99 sec. (0s default)




FILL./EMPT.:

it's possible to select the mode of pump control (filling or emptying)



ENABLE/DISABLE:


select ENABLE to allow the relay to work in the selected mode




RL2 DIAGNOSTIC:

it's possible to enable RL2 to activate its contact in case of error as:


- TEMP.: temperature out of range
- ECHO: no echo is detected
- GAIN: the sensor's gain exceed the value setted in Max Gain TH (3.4)
- DIST.: the measured distance exceed the 120% of the maximum distance in setup




NOTE: when an error occurs, a "I" is flashing on the display: press  to show a message that indicate what kind of error is present

DISPLAY (2)

From "RUN" mode press **OK**, then move the cursor on "DISPLAY" and confirm with **OK**



Select the parameters by moving the cursor with , and confirm with




DISPLAY VALUES:

It's possible to select if one value with big digits or two values are shown on the display in "RUN" mode




1 VALUE:

only one value is displayed; it's possible to choose from 5 parameters:



2 VALUES:

two values are displayed; it's possible to choose which one is the primary and which is the secondary, each with a choice of 5 parameters



ECHO MAP:

NOT YET AVAILABLE


CONTRAST:


it's possible to adjust the contrast of LCD, simply increasing or decreasing the value of a parameter from 0 to 63 (16 default)




DIAGNOSTIC (3)

From "RUN" mode press **OK**, then move the cursor on "DIAGNOSTIC" and confirm with **OK**



Select the parameters by moving the cursor with , and confirm with **OK**



FALSE ECHO DETECT:

It's possible to scan the empty tank in order to avoid obstacles like agitators' blades, limit switches, mechanical struts

It's necessary to input the empty distance (distance from the instrument to the bottom of the tank) and confirm with **OK**



The system will automatically scan and store all echoes separating false echoes from the real one that match the empty distance. After this, the following message is displayed: **FALSE ECHO DETECT DONE**

If something's not correct (e.g. wrong empty distance value, obstacles that hide the bottom) the following message is displayed **FALSE ECHO DETECT ERROR**


Note: False echo detect procedure is not recommended for pipe and stand-pipe applications

FALSE ECHO MAP:

NOT YET AVAILABLE


MEASURE STATUS:

it's possible to display the gain of the system, with values from 0 to 255. While displayed, the automatic gain control is not active



FROZEN GAIN:

it's possible to fix a value of gain (from 1 to 255) and consequently disable the automatic gain control. Once the value is 000 the automatic gain control restarts



MAX GAIN TH:

it's possible to input a value of gain that it should be not reached. If the gain is above this value, an error occurs




PEAK VALUES:

the system store the maximum distance and the minimum distance measured since the power is turned ON. It's possible to see those values or reset the



Select DISPLAY VALUES and confirm with **OK**




Select RESET VALUES and confirm with **OK** in order to cancel the stored values




OUTPUT SIMULATION:


it's possible to force the analog output to a desired value, simply by using **↑** and **↺** to modify that value. Confirm with **OK**. The output returns to its normal function in only in "RUN" mode.




SERVICE (4)

From "RUN" mode press **OK**, then move the cursor on "SERVICE" and confirm with **OK**




Select the parameters by moving the cursor with , and confirm with **OK**



OUTPUT SAFE MODE:

it's possible to choose a value of analog output during condition of system's internal errors.
Hold last value keep the output at the level corresponding at last valid measure.



COM MODE:

NOT YET ACTIVE

LANGUAGE:



NOT YET ACTIVE

PASSWORD:

NOT YET ACTIVE

CHECK FREQUENCY:

it's possible to check the computed emission frequency of the sensor.




INFO (5)




From "RUN" mode press **OK**, then move the cursor on "INFO" and confirm with **OK**

Informations about manufacturer, firmware version and serial number are displayed




METER Programming menu structure





Ordering code

METER



(Ordering code example)

METER Warranty

Products supplied by SGM LEKTRA are guaranteed for a period of 12 (twelve) months from delivery date according to the conditions specified in our sale conditions document.

SGM LEKTRA can choose to repair or replace the Product.

If the Product is repaired it will maintain the original term of guarantee, whereas if the Product is replaced it will have 12 (twelve) months of guarantee.

The warranty will be null if the Client modifies, repair or uses the Products for other purposes than the normal conditions foreseen by instructions or Contract.

In no circumstances shall SGM LEKTRA be liable for direct, indirect or consequential or other loss or damage whether caused by negligence on the part of the company or its employees or otherwise howsoever arising out of defective goods



METER Factory Test Certificate

In conformity to the company and check procedures I certify that the equipment:

METER Serial n.

is conform to the technical requirements on Technical Data and it is made in conformity to the SGM-LEKTRA procedure

Quality Control Manager

Production and check date



CERT. N. 2032308

SGM LEKTRA s.r.l.

Via Papa Giovanni XXIII, 49
20090 Rodano (Milano)
tel. ++39 0295328257 r.a.
fax ++39 0295328321

e-mail: info@sgm-lektra.com
web: www.sgm-lektra.com