


2017_04_08_12_04_14	2017/7/17 17:32	Microsoft Office Ex...	4 KB
2017_04_20_09_46_25	2017/7/17 17:32	Microsoft Office Ex...	9 KB
2017_04_20_09_51_09	2017/7/17 17:32	Microsoft Office Ex...	10 KB
2017_04_20_09_56_36	2017/7/17 17:32	Microsoft Office Ex...	138 KB
2017_04_20_11_19_10	2017/7/17 17:32	Microsoft Office Ex...	119 KB
2017_05_03_16_12_01	2017/7/17 17:32	Microsoft Office Ex...	20 KB
2017_05_03_18_09_07	2017/7/17 17:33	Microsoft Office Ex...	47 KB
2017_07_14_20_53_34	2017/7/17 17:33	Microsoft Office Ex...	40 KB
2017_07_17_17_34_21	2017/7/17 17:33	Microsoft Office Ex...	1 KB
报警记录_20170717173307	2017/7/17 17:33	Microsoft Office Ex...	1 KB
故障记录_20170717173307	2017/7/17 17:33	Microsoft Office Ex...	1 KB
开关机记录_20170717173306	2017/7/17 17:33	Microsoft Office Ex...	3 KB



軟件使用說明：

- 1) 以 USB 線，把便攜多合一檢測儀與電腦連接上
- 2) 打開軟件，選擇「導出」即可